

FITTING INSTRUCTIONS FOR FIAMMA AWNINGS

Please note that the saddles can't be used.

Measure down about 200mm from underside of housing and drill a 10mm hole through van side of face of leg.

This should be in the vicinity of the internal spring.

Insert plain hook end through one hole and turnbuckle through other.

Tighten turnbuckle until line is tight.

It is advisable to peg base of arms to the ground if possible to avoid movement when fitting line.